

Soda Siphon 1 Litre

Parts List

CO₂ cartridge sold separately

1. Body
2. Head
3. Cap
4. Cartridge Holder
5. Measuring Tube
6. Riser Tube with Gasket
7. Inner Tube Remover



Instructions

| | | |
|---|--|---|
| <p>1 Insert the Measuring Tube (5) in to the Soda Siphon Body (1). The measuring tube allows enough room for CO₂.</p>  | <p>2 Fill the Soda Siphon with cold water until the water reaches the brim of the measuring tube.</p>  | <p>3 Insert the Riser Tube with Gasket (6) in to the bottle through the measuring tube.</p>  |
| <p>4 Tightly screw the Soda Siphon Head (2) on to the assembled body.</p>  | <p>5 Insert a CO₂ cartridge (sold separately) in to the Cartridge Holder (4) and screw this on to the Soda Siphon Head until you hear the contents of the charger empty in to the Soda Siphon.</p>  | <p>6 Vigorously shake the assembled Soda Siphon to agitate the CO₂ and the water.</p>  |
| <p>7 Remove the Cartridge Holder and dispose of the CO₂ cartridge. Add the Cap (3).</p>  | <p>8 Dispense the carbonated contents of the Soda Siphon by directing the nozzle towards the side of your glass and depressing the lever on the head.</p>  | |

Tips

- Always make sure to clean your Soda Siphon before first use.
- Always fill with cold water - the colder it is, the more CO₂ it can absorb.
- Put the Soda Siphon in the fridge for a few hours before use.
- Keep a filled Soda Siphon in the fridge after use.
- If the Soda Siphon loses its fizz, shake it again to agitate the contents.
- After cleaning do not dry with a cloth, allow the components to air dry in a clean place.
- When storing, keep the Measuring Tube inserted in the body, and all other components disassembled.
- If the Soda Siphon has not been used for a long period of time, rinse with warm water before use.
- Empty CO₂ cartridges are recyclable and can be disposed of with your tin cans. Check with your local recycling services for more information.

Cleaning

- Depress the lever until the Soda Siphon is completely empty.
- Unscrew the Soda Siphon Head and remove.
- Remove the Riser Tube and Measuring Tube using the Inner Tube Remover.
- Rinse with clean water - do not use a scouring pad or boiling water.

Please Note: The Soda Siphon is NOT dishwasher safe.

Safety Instructions

- Never force open a pressurised Soda Siphon.
- Only use 1 CO₂ cartridge (sold separately) for the contents of your Soda Siphon.
- Only fill with water.
- Do not attempt to add more water by tilting the Soda Siphon.
- Never fill the Soda Siphon without the measuring tube inserted.
- Only operate the Soda Siphon when it is filled.
- Always ensure the Soda Siphon Head is screwed on straight.
- Do not lean over the Soda Siphon when screwing in the CO₂ charger.
- Do not heat the Soda Siphon.
- Never store a filled Soda Siphon in the freezer.
- Store the Soda Siphon in a safe place.
- Keep out of reach of children.